












Serie	Scan-Line 95
Description	Scan-Line 95 Steel



External fresh air from behind
0032-0015 (Not included)





External fresh air from below
1511-0028 (Not included)











Serie	Scan-Line 95
Description	Scan-Line 95R



External fresh air
from below
1515-0013 and 1500-022187
(Not included)





External fresh air
from behind
1511-0028 (Not included)











Serie	Scan-Line 95
Description	Scan-Line 95 Pederstal



External fresh air
from below
0032-0015





External fresh air from behind
1511-0028 (Not included)





Serie	Scan-Line 95
Description	Scan-Line 95 Turnable pederstal



External fresh air
from below
1515-0012
(Not included)

